

HEWLITT PACKARD PRINTERS

Model #	Instructions
HP4000	PRESS "MENU", GO TO "PRINT PAGE" AND PRINT A CONFIGURATION PAGE. THE METER IS THE "PAGES PRINTED" NUMBER.