

KYOCERA-M

KM-650

KM-830

KM-1530

KM-2030

KM-2530

KM-3530

KM-4030

KM-4850

KM-C830D

KM-2550

KM-3035

KM-4035

KM-5035

KM-C2030

KM-C3130

KM-4500

KM-4530

KM-5500

KM-5530

KM-6230

KM-6330

KM-1010

KM-1510

KM-1810
KM-1500

FS-3800

FS-8000

FS-9500

FS-C5016

MITA METER INSTRUCTIONS

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

THERE IS A MECHANICAL METER ON RIGHT SIDE OF MACHINE (LOOKS LIKE ODOMETER IN YOUR CAR).

Select [Counter Check} and press Enter. Select [Output count] and press Enter. Select [End] and press Enter. Select [Print counter report] and press enter to print report.

Hit the default settings/counter key on the top of the copier, then on the touch screen press counter check. There is a number under the word total-that is the meter to submit.

Hit the default settings/counter key on the top of the copier, then on the touch screen press counter check. There is a number under the word total-that is the meter to submit.

Hit the default settings/counter key on the top of the copier, then on the touch screen press counter check. There is a number under the word total-that is the meter to submit.

Go into utilities, hit meter count, there will be 2 print meters (1 black & white and 1 color) and there will be 2 copy meters (also 1 black & white and 1 color). Please make sure that you are submitting 4 separate meters.

Go into utilities, hit meter count, there will be 2 print meters (1 black & white and 1 color) and there will be 2 copy meters (also 1 black & white and 1 color). Please make sure that you are submitting 4 separate meters.

Open the front door, there is a mechanical meter on top left corner.

Open the front door, there is a mechanical meter on top left corner.

Open the front door, there is a mechanical meter on top left corner.

Open the front door, there is a mechanical meter on top left corner.

Open the front door – there will be 2 mechanical meters; the correct meter will be the second set of numbers on the bottom.

Open the front door – there will be 2 mechanical meters; the correct meter will be the second set of numbers on the bottom.

Press down the stop/reset key for approx. 5 seconds, it should flash f23 & then 2 sets of 3 numbers, write down all the numbers including zeros. Do not write down f23.

Press down the stop/reset key for approx. 5 seconds, it should flash f23 & then 2 sets of 3 numbers, write down all the numbers including zeros. Do not write down f23.

Press down the stop/reset key for approx. 5 seconds, it should flash f23 & then 2 sets of 3 numbers, write down all the numbers including zeros. Do not write down f23.
hold down the clear key

Press the menu key, scroll down to life counters; hit the right arrow key, you should see a set of numbers, that is the meter we need. To go back just hit the menu key.

Press the menu key, scroll down to life counters; hit the right arrow key, you should see a set of numbers, that is the meter we need. To go back just hit the menu key.

Press the menu key, scroll down to life counters; hit the right arrow key, you should see a set of numbers, that is the meter we need. To go back just hit the menu key.

Press the menu key, scroll down until you see print status page and enter twice, it will then print the page, please fax that to us along with the meter form we faxed you with your company information on it.